

Resin Drawer Unit

Installation Instructions:

1. Attach small part of drawer glides onto sides of resin drawer box by using flat head bolts (provided). After inserting bolts into holes located in the sides of the drawer box, place nuts onto bolts in the interior of the drawer box and tighten.

Be sure glides slide to the rear of drawer box.

2. Use pan head bolts (provided) to attach support brackets to outside of drawer glides.

3. Position front edge of drawer under work-surface at desired location relative to front edge.

4. Secure support brackets to underside of worksurface. (Bolts/screws not provided)

Parts included:

- 1- Resin Drawer box
- 1 pair of Drawer glides
- 1 pair of support brackets
- 4- 1/2" flat head bolts & nuts
- 4- 1/2" pan head bolts

