

Sturdi Wheelbarrow Holder

Installation Instructions:

1. Install lower support bracket into *storeWALL* panel at desired height and location. Place front lip of wheelbarrow onto support bracket and lift up on handles to determine position of upper brackets - back and front plates.

2. Insert back plate of upper bracket (with bolt inserted into one of holes) into desired *storeWALL* channel above back lip of wheelbarrow. Back plate and/or bolt location may vary according to size of wheelbarrow. Install front plate of upper bracket (with slot) onto bolt, place wing nut into position - do not tighten wing nut.

3. After placing front lip of wheelbarrow onto lower support bracket, lift up on handles and push wheelbarrow against *storeWALL* panels.

4. Slide front plate of upper bracket down onto back lip of wheelbarrow. Tighten wing nut.

Note: Top of upper bracket front plate must be above top bend of upper bracket back plate as far as possible to achieve a secure locking fit for wheelbarrow. Bolt location in upper bracket back plate may vary according to size of wheelbarrow.

Parts included:

- 1- Lower support bracket
- 1- Upper bracket back plate
- 1- Upper bracket front plate
- 1- 1" bolt
- 1- Wing nut

