



1. Please follow the instructions to complete the assembly steps 1-3.

2. fix two wall cleat (e) to the wall and ensure that the vertical distance between the upper and lower wall holes is 848mm. And make sure that enough space is reserved below.

3. Hang the cabinets on wall cleat. This step is recommended to be completed by two people.

4. Continue to complete step 6-10 according to assembly instructions until assembly is complete.

