
Grip-It Tool Holder

Installation Instructions



The Grip-It Tool Holder Package includes:

- Adjustable Grip-It
- Locking slatWALL Bracket (2 parts)
- Hardware
- 1. The Grip-It Tool Holder can be adjusted to 3 positions to fit the specific tool it will hold by simply adjusting the right side. Roller automatically adjusts to tool handle diameter.

(Grip-Its are adjustable to fit handles up to 2")

- 2. Insert the T-Nuts into the back molded slots of the Locking Bracket.
- 3. Attach the Grip-It Tool Holder to the Locking Bracket using the screws provided.
- 4. Insert the slatWALL-part of Locking Bracket into the slatWALL at desired location.
- 5. Slide the Grip-It Tool Holder in #3 onto Locking Bracket.
- 6. Slide the desired tool into the Grip-It Tool Holder.



GRIP-IT TOOL HOLDER PACKAGE



ADJUSTABLE GRIP-IT TOOL HOLDER











